

DVD Writer Installation


Follow these steps when Installing the DVD:



Ensure DVR is unplugged before DVD Writer Installation

1) Remove DVD Writer Bracket

Open the DVR cover. You will find the bracket as shown in this image. Loosen the screws and remove it.



2) Remove DVD Drive Cover

Release the plastic DVD Drive cover piece by pushing the two tabs that are holding it in place from the inside of the DVR.



3) Connect DVD Writer – IDE

Slide in the DVD Writer and connect the IDE cable and 4-pin Power plug.



IRES recommends using LG Multi Burner, model GH22NP20

4) Reconnect DVD Writer Bracket

Reconnect the bracket (removed in step #1).

5) Connect DVD Writer to Bracket

Secure the DVD Writer in the Bracket using appropriate screws. Reattach the DVR cover back onto the unit.

WARRANTY

IRES Technology warrants all of its products for one year, starting from the date of purchase. Please refer to the included Warranty card or go to www.IREStechology.com for more details. In no event shall IRES be liable for incidental, accidental or consequential damages arising from the use or inability to use its products.

Copyright © 2008 IRES Technology Corp.
Specifications are Subject to Change. E&OE

INSTALLATION INSTRUCTIONS



IRR3100 / 3200 / 3300 Series

Network DVR

Please read these Instructions
carefully before operating

This Quick Installation Guide covers the following:

- 1) HDD Installation – SATA
- 2) DVD Writer Installation – IDE

Depending on the system purchased, your DVR may not contain a HDD / DVD writer.



For more information visit:

www.IREStechology.com

HDD Installation

Follow these steps when Installing the HDD:



Ensure that the unit is unplugged before HDD Installation

1) Remove DVR Cover

To access the HDD connection, you must first open the DVR by removing the two screws at the back of the unit. Note that the remaining screws can be found in a bag along with other system accessories.

2) Remove HDD Bracket

You will find the HDD bracket within. Unscrew the Bracket shown in this image.



3) Connect HDD to Bracket

Using the supplied silver screws, secure the HDD into the bracket. The bracket can accommodate 2 HDD's: 1 Master & 1 Slave.

IREs recommends using Seagate or Western Digital brand HDD's.

4) Connect HDD – SATA

Connect any of the SATA Data/Power cables to the HDD. No HDD jumper settings are required. After connecting the SATA cable, reattach the bracket using the same screws removed in step #2.



5) Affix the Cover

Using the black screws provided, secure the DVR cover back onto the unit.

6) FORMAT HDD



Before you can Record, the HDD must first be Formatted via the DVR's Menu options.

Power up the DVR by pressing the Power button (after connecting the power supply, monitor and cameras).

6.1) LOGIN

Upon powering up, you will be asked for the User / Password. The factory default LOGIN is:
USER: admin / PASSWORD: 1234



You may enter this information using the Remote Control (press ENTER once complete) or use the USB Mouse.

6.2) Enter MENU

Press the "MENU" button on the Remote Control (or right-click the mouse and select "Menu"). Again, you will be asked to enter the Password before proceeding.



6.3) Enter System → HDD Submenu

Using the mouse, navigate to the SYSTEM section of the menu and click on the highlighted text. Then click on HDD in the sub-listing found on the right side of the screen.

6.4) Apply HDD Formatting

You will find checkboxes beside the HDD models recognized by the DVR. Check each HDD and then FORMAT. Wait until the Formatting is completed as indicated by the Progress Bar.



Once HDD formatting is complete, you are ready to record.